



# Plateia

by **CGS Labs**



## FILLETS Tutorial





**CGS Labs d.o.o.**

Brnčičeva ulica 13

1000 Ljubljana

**Fillets**

Copyright © 2022 CGS Labs d.o.o. All rights reserved.

Title: **Fillets**

Document date: 08. 08. 2022

Version: 1.0.

Printing: CGS Labs d.o.o.

T: +386 1 235 06 00

E: [info@cgs-labs.com](mailto:info@cgs-labs.com)

Internet: [www.cgs-labs.com](http://www.cgs-labs.com)

## Table of Contents

INTRODUCTION .....	3
Draw a fillet .....	4
Insert a Profile View .....	5
Draw a profile .....	6
Show intersection.....	6
Edit the profile of the fillet .....	7
Draw 3D road edges .....	8


## INTRODUCTION

The Fillet command group comprises three types of transition curves:

- transition curve with one arc: you need to enter only an arc radius.
- transition curve with two arcs: using this type, you need to enter both radii and angle ratio between them.
- transition curve with three arcs: using this fillet type, enter the middle arc radius and a ratio between all three radii. Not to forget the angles: The R2 radius angle is 15.74 centesimal degrees and the one with the R3 radius is 20.25 centesimal degrees while the angle with the middle radius gets calculated according to the selected curve geometry.

Before you start drawing any of these three fillets, you must have two intersecting axes drawn in your drawing.

In this example, AXIS\_01 is the major alignment and AXIS\_02 is the minor alignment.



## Draw a fillet


1. Run the Fillet command.
2. Define the radius in meters.
3. Select entry and exit road edge. Click on the icon and select edges directly in the drawing.




4. From the drop-down menu, select the option to draw the fillet as a Plateia axis.
5. Define the alignment name.

*Some options are hidden and only available if you select Civil's alignment from the drop-down menu.*

6. Confirm by clicking OK.




The following figures show the drawn fillet. In the 3D view, only the terrain line is drawn, since the fillet does not have yet a defined height position.



## Insert a Profile View

1. In the Alignment manager double-click on the FILLET\_01 axis to set it as an active alignment.




2. Run the Draw Profile View command.



3. In the Input terrain dialogue box specify:

- Scale: 1000:100
- Input Data: \*current drawing\*
- From station: select the first sample line
- To station: select the last sample line
- Check: Labeling
  - Draw verticals
  - Draw horizontal elements
  - Horizontal road elements
  - Lane widths
  - Lane widenings




4. Confirm by pressing OK.


5. Define the insertion point in the drawing.



1. Run the Intersection command.
2. Select layout DWG from the drop-down menu.
3. Select longitudinal profile DWG from the drop-down menu.
4. Mark AXIS\_01 [PLATEIA] and AXIS\_02 [PLATEIA].
5. Confirm by pressing the OK button.




The height of the axis AXIS\_01 and AXIS\_02 are now drawn in the profile FILLET\_01 as shown in the figure on the right. They are coloured blue for easier presentation.



## Edit the profile of the fillet


Now it is necessary to adjust the profile of the FILLET\_01 according to AXIS\_01 and AXIS\_02 profiles. To edit the profile, use the tools from the Editing profile tab.

1. Run the Move PVI command.
2. Change the position of the profile to fit the axes AXIS\_01 and AXIS\_02.




## Draw 3D road edges

1. Run the Draw Road Edges in 3D command.



2. Select lanes in the dialogue box by clicking on them.

3. Confirm by clicking OK.



The fillet is now drawn in 3D.

