

# Plateia by CGS-labs

## Create Longitudinal Alignment

### Tutorial





**CGS Labs d.o.o.**

Brnčičeva ulica 13

1000 Ljubljana

## **Create longitudinal alignment Tutorial**

Copyright © 2020 CGS Labs d.o.o. All rights reserved.

Title: **Create longitudinal alignment Tutorial**

Document date: 15. 06. 2020

Version: 3.0.

Printing: CGS Labs d.o.o.

T: +386 1 235 06 00

E: [info@cgs-labs.com](mailto:info@cgs-labs.com)

Internet: [www.cgs-labs.com](http://www.cgs-labs.com)

## Table of content

<b>INTRODUCTION.....</b>	<b>3</b>
<b>1. Draw with Floating Elements .....</b>	<b>3</b>
<b>2. Draw with Tangent Polygon .....</b>	<b>6</b>
<b>3. Draw with Stick Method.....</b>	<b>7</b>
<b>4. Convert Polyline to TP .....</b>	<b>9</b>
<b>5. Convert Pline to Alignment .....</b>	<b>10</b>
<b>6. Create Best Fit Alignment.....</b>	<b>11</b>

# INTRODUCTION


Plateia contains different commands to define alignment elements. The longitudinal alignment can be defined using the following alignment elements: tangent, curve, spiral and compound spiral. Horizontal elements can be drawn as independent objects or as combinations between existing construction elements. When creating and editing horizontal alignment elements, the horizontal elements and their combinations must always be created in the direction of the station increase.

## 1. Draw with Floating Elements


1. Start with **Layout Ribbon Panel**.

2. To draw an alignment with floating elements, construction elements (tangent or circle) need to be drawn in the drawing first. Click on **Fixed Element** icon.

3. Draw Arc +/ Arc – / Line element. When finished, click on the icon **Draw with floating elements**.



4. The command interface differs based on a combination of construction elements that have been selected. There are several combinations possible, from single construction element (tangent or circle), tangent – circle combinations to circle – circle combinations which include circle orientation in same or opposite direction.




5. Select the first and second fixed element and press **Enter**.



6. The following dialog box of combinations to draw floating elements open up (which dialog box of combinations open depends on selected combination of construction elements). In this tutorial are presented three possible combinations.

### 1. tangent – circle combination

After the selection of the tangent and circle construction elements the following dialog box opens up:






Select the proper combination. Then the detailed user interface opens, where the radius value can be defined. Press OK to draw the alignment.



## 2. circle – circle combinations




After the selection of two circles construction elements in the following dialog box select the proper combination and in the detailed user interface define specific parameters, like the length of spiral or radius value.






### 3. Tangent-tangent combinations

Based on two construction tangent elements, three different combinations of floating horizontal elements creation are possible. Select the proper combination and in the detailed user interface define the length of spiral or radius value.



In the *Draw lanes and widenings* dialog box choose appropriate vehicle combination.





## 2. Draw with Tangent Polygon

1. To design an alignment with tangent polygon, click on **Draw with Tangent Polygon** icon. Using a tangent polygon, you can describe any combination of main elements.

2. After invoking the command, the *Create Tangent Polygon* dialog box appears.

3. Click OK and then in the drawing define the first point of tangent polygon. Continue with a selection of more points to create a tangent polygon.


4. In *Draw lanes and widenings* dialog box, you chose vehicle combination to calculate widenings. Alignment parameters such as spiral lengths and radius values are calculated based on design speed defined in alignment name *Category definition*.



### 3. Draw with Stick Method



With this method, command **Draw with Stick Method**, you “stick” the horizontal elements together in a sequence.

1. Click on the icon **Draw with Stick Method**.
2. Select a start point of the first element or the horizontal alignment element from which you want to continue your drawing.
3. A dialog box that appears has three tabs for drawing: line, arc, and spiral. Some of the parameters found in the tab are fixed and cannot be modified according to the previous element. This tutorial shows how to draw a section of the line, spiral and arc.





#### 1. Drawing line

1. Define direction and length or an end point of the line.
2. You can enter parameters manually to the appropriate field or select them interactively by selecting the button  and dragging the auxiliary line in the drawing.
3. Press *Draw* to get your horizontal element drawn with its labels included.




## 2. Spiral drawing


- You can define a spiral in three ways.
  - you can define a start point, start angle and end point,
  - you can define a start point, start angle, radius and length,
  - you can define the start point, start angle and the A parameter.
- In case the radius, length or parameter haven't been defined, you just select a spiral end point by pressing  and define it in the drawing.
- Click *Draw* to get horizontal element drawn.




## 3. Arc drawing

- Arc can be defined using three different methods.
  - In the first method define three points,
  - in the second one define the start point, start angle and end point,
  - in the third one define a start point, start angle, radius and length.
- Also arcs parameters can be defined manually or by dragging an auxiliary arc with the button .
- Press *Draw*.






4. By pressing the button *Back* you can go one step back. Program erases the last drawn element and continues its drawing from the previous one.
5. Click *End* to finish your drawing.
6. After drawing main elements, the *Draw lanes and widening* dialog box appears, where you choose appropriate vehicle combination to calculate widenings.




#### 4. Convert Polyline to TP

Use the command [Convert Polyline to Tangent Polygon](#) to convert any polyline to a tangent polygon. On the basis of a tangent polygon defined, main elements are drawn and labeled.

1. Click on [Convert Polyline to TP](#) icon.
2. Select a polyline to be converted.







3. In *Create Tangent Polygon* click *OK*.

4. In *Draw lanes and widenings* select vehicle combination to calculate widenings.


5. The program converts a polyline to a tangent polygon.




## 5. Convert Pline to Alignment

With command *Convert Pline to Alignment*, you can convert two-dimensional polyline in the horizontal elements of an axis.

1. Draw a polyline and arc.
2. Click on *Convert PLINE to Alignment* icon and select the polylines/arcs.
3. Straight polyline sections are converted to tangents and arcs to curves.



4. After converting the polyline to horizontal alignment elements, the original polyline is automatically erased from the drawing.



## 6. Create Best Fit Alignment


The command **Create BestFit Alignment** on the basis of the given sequence of points or the polyline calculates and draws BestFit alignment that best fits the given elements.

1. Click on **Create BestFit Alignment** icon.
2. After the start of the command *Bestfit Alignment* dialog box appears.

3. As input data, it is possible to give one or two (parallel) sequences of points or one or two (parallel) polylines, where the program can read points from.

First specified whether BestFit alignment will be created from one or two sets of input objects.

- If you select option *One string*, the alignment will be created through a single set of blocks or Polyline vertices, representing roadway/railway alignment.
- If you select option *Two strings*, then it's required to select two different values for block's attributes, representing right and left roadway edges.



4. In the next step define what kind of data will be used.

- If you select the *AutoCAD blocks*, you can define *Weeding setting* under *Parameters* button, which opens the right dialog box.

After defining the weeding options press *OK* and continue with the selection of the value of a point attribute that will be used for creating the BestFit alignment. In the *Attribute name* pull down menu select the attribute name of points and then in the *Point attribute* choose the value of a point attribute that will be used to create the BestFit alignment.

- If you want to create a BestFit alignment from polyline, choose *Polyline* check box and select the polyline that will be used to create the alignment.
- 


5. Check *Draw as Tangent Polygon* to design an alignment with tangent polygon.


6. Check the *Show report* check box to draw BestFit reports, including the regression analysis result.

7. Confirm with *OK*.



8. In *Draw lanes and widenings* select vehicle combination and confirm with *OK* to draw the widenings.

9. Output data is the alignment with main elements that best follows the course of the given elements. To input regression analysis results in the drawing select *Place diagram in DWG* and define the location of the report in the drawing.





An example of a sequence of points:



An example of a sequence of two polylines:

